



IMPORTANT: See the machine and/or engine parts manual for related parts.

IMPORTANT: Parts listed are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted.

DEALER REFERENCE LIST

Table of Contents
 R Series, Page 1
 V Series, Page 1-2
 SL Series, Pages 2-13

Starters and Starter Solenoids - Skid Loader

Quick Reference List



| Model | Engine Make | Engine Model & Description | Skid Loader Serial Number | Engine Serial Number & Notes | Starter | | | Starter Solenoid |
|-------|-------------|----------------------------|---------------------------|------------------------------|---|-----|-------------|------------------|
| | | | | | Standard | OEM | Tooth Count | |
| | | | | | Order both Standard and OEM part numbers through Gehl, unless noted | | | |

R Series

| | | | | | | | | |
|------|--------|------------------|--|--|--------|--|----|--------|
| R135 | Yanmar | 4TNV88C - KMS | | | 188586 | | 15 | |
| R150 | Yanmar | 4TNV88C - KMS | | | 188586 | | 15 | |
| R165 | Yanmar | 4TNV98C - NMS2 | | | 194316 | | 9 | 197725 |
| R190 | Yanmar | 4TNV98C- NMS/T4 | | | 194316 | | 9 | 197725 |
| R220 | Yanmar | 4TNV98CT- NMS/T4 | | | 194316 | | 9 | 197725 |
| R260 | Yanmar | 4TNV98CT- NMS/T4 | | | 194316 | | 9 | 197725 |

V Series

| | | | | | | | | |
|------|--------|--|--|--|--------|--|---|--------|
| V270 | Yanmar | 4TNV98CT-NMS Tier IV 4TNV98T-ZNMS 4-cylinder turbo | | | 194316 | | 9 | 197725 |
|------|--------|--|--|--|--------|--|---|--------|



IMPORTANT: See the machine and/or engine parts manual for related parts.


IMPORTANT: Parts listed are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted.

DEALER REFERENCE LIST

Table of Contents
 R Series, Page 1
 V Series, Page 1-2
 SL Series, Pages 2-13

Starters and Starter Solenoids - Skid Loader

Quick Reference List



| Model | Engine Make | Engine Model & Description | Skid Loader Serial Number | Engine Serial Number & Notes | Starter | | | Starter Solenoid |
|-------|-------------|---|---------------------------|------------------------------|---|----------|-----|--|
| | | | | | Order both Standard and OEM part numbers through Gehl, unless noted | Standard | OEM | |
| V330 | Yanmar | 4TNV98CT-NMS Tier IV 4TNV98T-ZNMS 4-cylinder turbo | | | 194316 | | 9 | 197725 |
| V400 | Cummins | QSB4.5 | | | 50350436 | | | Solenoid included with 50350436, not sold separately |

SL Series

| | | | | | | | | |
|------|--------|-------------------------------------|-----------------|------------------------|-------------|--|----|--|
| 1640 | Yanmar | 3TNV82 BPMS 3-cylinder non-turbo | | | 198140 | | 11 | 198141 |
| 3310 | Onan | P220 2-cylinder non-turbo | 1501 and Up | Onan part numbers only | 191-1949-04 | | | |
| 3310 | Onan | B48G 2-cylinder non-turbo | 1500 and Before | Onan part numbers only | 191-1808-01 | | | |
| 3410 | Isuzu | QT23 3KC1 | | | 083702 | | 9 | Solenoid included with 083702, not sold separately |



IMPORTANT: See the machine and/or engine parts manual for related parts.

IMPORTANT: Parts listed are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted.

DEALER REFERENCE LIST

Table of Contents
 R Series, Page 1
 V Series, Page 1-2
 SL Series, Pages 2-13

Starters and Starter Solenoids - Skid Loader

Quick Reference List



| Model | Engine Make | Engine Model & Description | Skid Loader Serial Number | Engine Serial Number & Notes | Starter | | | Starter Solenoid |
|-------|-------------|--|---------------------------|------------------------------|---|-----|-------------|--|
| | | | | | Order both Standard and OEM part numbers through Gehl, unless noted | | | |
| | | | | | Standard | OEM | Tooth Count | |
| 3510 | Ford | VSG-411 I-67 1.1L, 4-cylinder non-turbo | 2420 and Up | Ford part number only | 129275 | | | |
| 3510 | Ford | KSG-411 I-67 1.1L, 4-cylinder non-turbo | 2419 and Before | | 082217 (OBS) - Call Parts Support | | 10 | Solenoid included with 082217, not sold separately |
| 3515 | Ford | VSG-411 I-67 1.1L, 4-cylinder non-turbo | 6826 and Up | Ford part number only | 129275 | | | |
| 3515 | Ford | VSG-411 I-67 1.1L, 4-cylinder non-turbo | 6825 and Before | | 082217 (OBS) - Call Parts Support | | 10 | Solenoid included with 082217, not sold separately |
| 3610 | Isuzu | QT 35 3KR1 | 2001 and Up | | 083702 | | 9 | Solenoid included with 083702, not sold separately |
| 3610 | Isuzu | QD 27 2-cylinder non-turbo | 2000 and Before | Isuzu part number only | 8-9417-0205 | | | |
| 3615 | Isuzu | QT 35 3KR1 | | | 083702 | | 9 | Solenoid included with 083702, not sold separately |



IMPORTANT: See the machine and/or engine parts manual for related parts.

IMPORTANT: Parts listed are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted.

DEALER REFERENCE LIST

Table of Contents
 R Series, Page 1
 V Series, Page 1-2
 SL Series, Pages 2-13

Starters and Starter Solenoids - Skid Loader

Quick Reference List



| Model | Engine Make | Engine Model & Description | Skid Loader Serial Number | Engine Serial Number & Notes | Starter | | | Starter Solenoid |
|-------|-------------|--|---------------------------|------------------------------|---|-----|-------------|--|
| | | | | | Order both Standard and OEM part numbers through Gehl, unless noted | | | |
| | | | | | Standard | OEM | Tooth Count | |
| 3635 | Yanmar | 3TNV88-XMS 3-cylinder non-turbo | 1175 and Up | | 425-36290 | | 15 | 425-34994 |
| 3635 | Yanmar | 3TNE88 3-cylinder non-turbo | 1174 and Before | | 425-36290 | | 15 | 425-34994 |
| 3640 | Yanmar | 3TNV88-BKMS | 3701 and Up | | 188586 | | 15 | 188587 |
| 3640 | Yanmar | 3TNV88-XMS2 | 3700 and Before | | 425-36290 | | 15 | 425-34994 |
| 3725 | Ford | VSG-413 I-79 1.3L, 4-cylinder non-turbo | 7820 and Up | | 129275 | | 10 | Solenoid included with 129275, not sold separately |
| 3725 | Ford | VSG-411 I-67 1.1L, 4-cylinder non-turbo | 7819 and Before | Ford part number only | 129275 | | | |
| 3825 | Kubota | V1305 4-cylinder non-turbo | | | 121959 | | 9 | Solenoid included with 121959, not sold separately |
| 3840 | Yanmar | 3TNV88-BKMS | 4001 and Up | | 188586 | | 15 | 188587 |
| 3840 | Yanmar | 3TNV88-XMS2 | 4000 and Before | | 425-36290 | | 15 | 425-34994 |



IMPORTANT: See the machine and/or engine parts manual for related parts.

IMPORTANT: Parts listed are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted.

DEALER REFERENCE LIST

Table of Contents
 R Series, Page 1
 V Series, Page 1-2
 SL Series, Pages 2-13

Starters and Starter Solenoids - Skid Loader

Quick Reference List



| Model | Engine Make | Engine Model & Description | Skid Loader Serial Number | Engine Serial Number & Notes | Starter | | | Starter Solenoid |
|-------|-------------|--|---------------------------|------------------------------|---|----------|-----|--|
| | | | | | Order both Standard and OEM part numbers through Gehl, unless noted | Standard | OEM | |
| 3935 | Yanmar | 3TNV88-XMS 3-cylinder non-turbo | 1337 and Up | | 425-36290 | | 15 | 425-34994 |
| 3935 | Yanmar | 3TNE88 3-cylinder non-turbo | 1336 and Before | | 425-36290 | | 15 | 425-34994 |
| 4240 | Yanmar | 4TNV88-BKMS | 5401 and Up | | 425-35508 | | 15 | 425-35908 |
| 4240 | Yanmar | 4TNV88-XMS2 4-cylinder non-turbo | 5400 and Before | | 425-35508 | | 15 | 425-35908 |
| 4400 | Ford | 134G 4-cylinder non-turbo | | Ford part number only | SA713-BM | | | |
| 4400 | Perkins | 4.108 4-cylinder non-turbo | | | 096216 | | 12 | Solenoid included with 096216, not sold separately |
| 4500 | Ford | KSG-416 I-98 1.6L, 4-cylinder non-turbo | | | 082217 (OBS) - Call Parts Support | | 10 | Solenoid included with 082217, not sold separately |
| 4510 | Ford | VSG-413 I-79 1.3L, 4-cylinder non-turbo | 5501 and Up | Ford part number only | 129275 | | | |



IMPORTANT: See the machine and/or engine parts manual for related parts.


IMPORTANT: Parts listed are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted.

DEALER REFERENCE LIST

Table of Contents
 R Series, Page 1
 V Series, Page 1-2
 SL Series, Pages 2-13

Starters and Starter Solenoids - Skid Loader

Quick Reference List



| Model | Engine Make | Engine Model & Description | Skid Loader Serial Number | Engine Serial Number & Notes | Starter | | | Starter Solenoid |
|-------|-------------|--|---------------------------|------------------------------|---|----------|-----|--|
| | | | | | Order both Standard and OEM part numbers through Gehl, unless noted | Standard | OEM | |
| 4510 | Ford | KSG-416 I-98 1.6L, 4-cylinder non-turbo | 5500 and Before | | 082217 (OBS) - Call Parts Support | | 10 | Solenoid included with 082217, not sold separately |
| 4515 | Ford | VSG-413 I-79 1.3L, 4-cylinder non-turbo | 6131 and Up | Ford part number only | 129275 | | | |
| 4515 | Ford | KSG-416 I-98 1.6L, 4-cylinder non-turbo | 6130 and Before | | 082217 (OBS) - Call Parts Support | | 10 | Solenoid included with 082217, not sold separately |
| 4525 | Ford | VSG-413 I-79 1.3L, 4-cylinder non-turbo | 9101 and Up | | 129275 | | 10 | Solenoid included with 129275, not sold separately |
| 4525 | Ford | VSG-413 I-79 1.3L, 4-cylinder non-turbo | 9100 and Before | Ford part number only | 129275 | | | |
| 4610 | Perkins | 4.19 4-cylinder non-turbo | 8501 and Up | Perkins part number only | 185086560 2-Bolt | | | |
| 4610 | Perkins | 4.108 4-cylinder non-turbo | 8500 and Before | | 096216 3-Bolt | | 12 | Solenoid included with 096216, not sold separately |



IMPORTANT: See the machine and/or engine parts manual for related parts.

IMPORTANT: Parts listed are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted.

DEALER REFERENCE LIST

Table of Contents
 R Series, Page 1
 V Series, Page 1-2
 SL Series, Pages 2-13

Starters and Starter Solenoids - Skid Loader

Quick Reference List



| Model | Engine Make | Engine Model & Description | Skid Loader Serial Number | Engine Serial Number & Notes | Starter | | | Starter Solenoid |
|---------------|-------------|----------------------------------|---------------------------|------------------------------|---|----------|-----|--|
| | | | | | Order both Standard and OEM part numbers through Gehl, unless noted | Standard | OEM | |
| 4615 | Perkins | 4.19 4-cylinder non-turbo | 14201 and Up | Perkins part number only | 185086560 | | | |
| 4615 | Perkins | 4.108 4-cylinder non-turbo | 14200 and Before | | 096216 | | 12 | Solenoid included with 096216, not sold separately |
| 4625 | Kubota | V2203 4-cylinder non-turbo | | | 127592 | | 9 | Solenoid included with 127592 not sold separately |
| 4635SX | Deutz | F3M1011F 3-cylinder non-turbo | | 618516 and Up | 188125 | 138859 | 9 | 133301 |
| 4635SX | Deutz | F3M1011F 3-cylinder non-turbo | | 618515 and Before | 188119 | 133557 | 11 | 133301 |
| 4635SXT / DXT | Deutz | BF3M1011F 3-cylinder turbo | | 618576 and Up | 188125 | 138859 | 9 | 133301 |
| 4635SXT / DXT | Deutz | BF3M1011F 3-cylinder turbo | | 618575 and Before | 188119 | 133557 | 11 | 133301 |
| 4640 | Yanmar | 4TNV98-ZNMS2 | 312901 and Up | | 194316 | | 9 | 197725 |



IMPORTANT: See the machine and/or engine parts manual for related parts.

IMPORTANT: Parts listed are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted.

DEALER REFERENCE LIST

Table of Contents
 R Series, Page 1
 V Series, Page 1-2
 SL Series, Pages 2-13

Starters and Starter Solenoids - Skid Loader

Quick Reference List



| Model | Engine Make | Engine Model & Description | Skid Loader Serial Number | Engine Serial Number & Notes | Starter | | | Starter Solenoid |
|----------------|-------------|--|---------------------------------------|------------------------------|---|--------|-------------|--|
| | | | | | Order both Standard and OEM part numbers through Gehl, unless noted | | | |
| | | | | | Standard | OEM | Tooth Count | |
| 4640 | Deutz | TD2009L04 4-cylinder in-line turbo | 311123 and Up, except 311128 & 311133 | 9308771 and Up | 105941 | | 10 | Solenoid included with 105941, not sold separately |
| 4640 | Deutz | TD2009L04 4-cylinder in-line turbo | 310601-311122 and SNs 311128 & 311133 | 9308770 and Before | 105243 | | 11 | Solenoid included with 105243, not sold separately |
| 4640 | Deutz | F3M2011F 3-cylinder non-turbo | 310600 and Before | | 188125 | 138859 | 9 | 133301 |
| 4640 | Deutz | BF3M2011F 3-cylinder turbo | 310600 and Before | | 188125 | 138859 | 9 | 133301 |
| 4700 | Ford | KSG-416 I-98 1.6L, 4-cylinder non-turbo | | | 082217 (OBS) - Call Parts Support | | 10 | Solenoid included with 082217, not sold separately |
| 4835 SXT / DXT | Deutz | BF3M1011F 3-cylinder turbo | | 618576 and Up | 188125 | 138859 | 9 | 133301 |
| 4835 SXT / DXT | Deutz | BF3M1011F 3-cylinder turbo | | 618575 and Before | 188119 | 133557 | 11 | 133301 |



IMPORTANT: See the machine and/or engine parts manual for related parts.

IMPORTANT: Parts listed are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted.

DEALER REFERENCE LIST

Table of Contents
 R Series, Page 1
 V Series, Page 1-2
 SL Series, Pages 2-13

Starters and Starter Solenoids - Skid Loader

Quick Reference List



| Model | Engine Make | Engine Model & Description | Skid Loader Serial Number | Engine Serial Number & Notes | Starter | | | Starter Solenoid |
|-------|-------------|----------------------------------|--|------------------------------|---|--------|-------------|--|
| | | | | | Order both Standard and OEM part numbers through Gehl, unless noted | | | |
| | | | | | Standard | OEM | Tooth Count | |
| 4840 | Deutz | F4M2011F 4-cylinder non-turbo | | | 188125 | 138859 | 9 | 133301 |
| 5240 | Yanmar | 4TNV98-ZNMS2 | 432501 and Up | | 194316 | | 9 | 197725 |
| 5240 | Deutz | TD 2009 L4 4-cylinder turbo | 430586 - 432500, except SN 430604 and 430616 | | 105941 | | 10 | Solenoid included with 105941, not sold separately |
| 5240 | Deutz | TD 2009 L4 4-cylinder turbo | 430585 and Before, and 430604 and 430616 | | 105243 | | 11 | Solenoid included with 105243, not sold separately |
| 5620 | Perkins | 4.154 4-cylinder non-turbo | | | 096216 | | 12 | Solenoid included with 096216, not sold separately |
| 5625 | Perkins | 204.25 4-cylinder non-turbo | 8868 and Up | | 128179 | | 13 | Solenoid included with 128179, not sold separately |




IMPORTANT: See the machine and/or engine parts manual for related parts.

IMPORTANT: Parts listed are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted.

DEALER REFERENCE LIST

Table of Contents
 R Series, Page 1
 V Series, Page 1-2
 SL Series, Pages 2-13

Starters and Starter Solenoids - Skid Loader
Quick Reference List



| Model | Engine Make | Engine Model & Description | Skid Loader Serial Number | Engine Serial Number & Notes | Starter | | | Starter Solenoid |
|----------------|-------------|----------------------------------|---------------------------|------------------------------|---|--------|-------------|--|
| | | | | | Order both Standard and OEM part numbers through Gehl, unless noted | | | |
| | | | | | Standard | OEM | Tooth Count | |
| 5625 | Perkins | 4.154 4-cylinder non-turbo | 8867 and Before | | 096216 | | 12 | Solenoid included with 096216, not sold separately |
| 5635 SXT / DXT | Deutz | BF4M1011F 4-cylinder turbo | | 618098 and Up | 188125 | 138859 | 9 | 133301 (on starter), 187964 (on machine) |
| 5635 SXT / DXT | Deutz | BF4M1011F 4-cylinder turbo | | 618097 and Before | 188119 | 133557 | 11 | 133301 (on starter), 187964 (on machine) |
| 5635SX | Deutz | F4M1011F 4-cylinder non-turbo | | 618182 and Up | 188125 | 138859 | 9 | 133301 (on starter), 187964 (on machine) |
| 5635SX | Deutz | F4M1011F 4-cylinder non-turbo | | 618181 and Before | 188119 | 133557 | 11 | 133301 (on starter), 187964 (on machine) |
| 5640 | Yanmar | 4TNV98T-ZNMS 4-cylinder turbo | 511701 and Up | | 194316 | | 9 | 197725 |
| 5640 | Deutz | F4M2011F 4-cylinder non-turbo | 511700 and Before | | 188125 | 138859 | 9 | 133301 |
| 5640 | Deutz | BF4M2011F 4-cylinder turbo | 511700 and Before | | 188125 | 138859 | 9 | 133301 |



IMPORTANT: See the machine and/or engine parts manual for related parts.

IMPORTANT: Parts listed are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted.

DEALER REFERENCE LIST

Table of Contents
 R Series, Page 1
 V Series, Page 1-2
 SL Series, Pages 2-13

Starters and Starter Solenoids - Skid Loader

Quick Reference List



| Model | Engine Make | Engine Model & Description | Skid Loader Serial Number | Engine Serial Number & Notes | Starter | | | Starter Solenoid |
|----------------|-------------|--------------------------------|---------------------------|------------------------------|---|----------|-----|--|
| | | | | | Order both Standard and OEM part numbers through Gehl, unless noted | Standard | OEM | |
| 6620 | Perkins | 4.154 4-cylinder non-turbo | | | 096216 | | 12 | Solenoid included with 096216, not sold separately |
| 6625 | Perkins | 204.30 4-cylinder non-turbo | 7605 and Up | | 128179 | | 13 | Solenoid included with 128179, not sold separately |
| 6625 | Perkins | 4.154 4-cylinder non-turbo | 7604 and Before | | 096216 | | 12 | Solenoid included with 096216, not sold separately |
| 6635 SXT / DXT | Deutz | BF4M1011F 4-cylinder turbo | | 618098 and Up | 188125 | 138859 | 9 | 133301 (on starter), 187964 (on machine) |
| 6635 SXT / DXT | Deutz | BF4M1011F 4-cylinder turbo | | 618097 and Before | 188119 | 133557 | 11 | 133301 (on starter), 187964 (on machine) |
| 6640 | Yanmar | 4TNV98T 4-cylinder turbo | 608301 and Up | | 194316 | | 9 | 197725 |
| 6640 | Deutz | BF4M2011F 4-cylinder turbo | 608300 and Before | | 188125 | 138859 | 9 | 133301 |



IMPORTANT: See the machine and/or engine parts manual for related parts.

IMPORTANT: Parts listed are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted.

DEALER REFERENCE LIST

Table of Contents
 R Series, Page 1
 V Series, Page 1-2
 SL Series, Pages 2-13

Starters and Starter Solenoids - Skid Loader

Quick Reference List



| Model | Engine Make | Engine Model & Description | Skid Loader Serial Number | Engine Serial Number & Notes | Starter | | | Starter Solenoid |
|-------|-------------|----------------------------------|---------------------------|---|---|-----|-------------|--|
| | | | | | Order both Standard and OEM part numbers through Gehl, unless noted | | | |
| | | | | | Standard | OEM | Tooth Count | |
| 7600 | Yanmar | 4TNE106 4-cylinder non-turbo | | If replacing 138044 for the first time, order 188160. If 188160 is already installed on the skid loader, order 186899 to replace the starter. | 188160 (Kit) 186899 (Starter only) | | 11 | Solenoid included with starter, not sold separately. |
| 7610 | Perkins | 1104C-44 4-cylinder non-turbo | | | 184235 | | 10 | Solenoid included with 184235, not sold separately. |
| 7800 | Yanmar | 4TNE106T 4-cylinder turbo | | If replacing 138044 for the first time, order 188160. If 188160 is already installed on the skid loader, order 186899 to replace the starter. | 188160 (Kit) 186899 (Starter only) | | 11 | 186899 - Solenoid included with starter, not sold separately. 138044 - 138102 is the starter solenoid for 138044 only. It cannot be used on 186899. |



IMPORTANT: See the machine and/or engine parts manual for related parts.

IMPORTANT: Parts listed are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted.

DEALER REFERENCE LIST

Table of Contents
 R Series, Page 1
 V Series, Page 1-2
 SL Series, Pages 2-13

Starters and Starter Solenoids - Skid Loader
Quick Reference List



| <u>Model</u> | <u>Engine Make</u> | <u>Engine Model & Description</u> | <u>Skid Loader Serial Number</u> | <u>Engine Serial Number & Notes</u> | <u>Starter</u> | | | <u>Starter Solenoid</u> |
|--------------|--------------------|---------------------------------------|----------------------------------|---|---|-----------------|------------|---|
| | | | | | Order both Standard and OEM part numbers through Gehl, unless noted | <u>Standard</u> | <u>OEM</u> | |
| 7810 | Perkins | 1104C-E44T 4-cylinder turbo | 903001 - 904501 | | 184235 | | 10 | Solenoid included with 184235, not sold separately. |
| 7810E | Cummins | B4.5T 4-cylinder turbo | 904502 and Up | | 191133 | | 10 | Solenoid included with 191133, not sold separately. |

Notes



IMPORTANT: See the machine and/or engine parts manual for related parts.

IMPORTANT: Parts listed are the same for GEN:1, GEN:2, Series I and Series II, E and non E series, EU, SX, SXT, DX, DXT machines unless noted.

DEALER REFERENCE LIST

Table of Contents
 R Series, Page 1
 V Series, Page 1-2
 SL Series, Pages 2-13

Starters and Starter Solenoids - Skid Loader
Quick Reference List



| <u>Model</u> | <u>Engine Make</u> | <u>Engine Model & Description</u> | <u>Skid Loader Serial Number</u> | <u>Engine Serial Number & Notes</u> | <u>Starter</u> | | | <u>Starter Solenoid</u> |
|--------------|--------------------|---------------------------------------|----------------------------------|---|---|-----------------|------------|-------------------------|
| | | | | | Order both Standard and OEM part numbers through Gehl, unless noted | <u>Standard</u> | <u>OEM</u> | |
| | | | | | | | | |

Notes